



## Arné Gunter




John and Amy's Timber Home







Building Section S-02 Building Section S-03




g Section S-03




3D Assembly View




Typical Window / Door Module Plan





Full Wall Panel Module Half Wall Panel Module




Typical Wall Panel Module Plan

























High Tensile Blind Nut Assembly











